

Firmware Upgrade Instruction

1st Step: Disable your PC computer webcam firstly,

to prevent the risk that the firmware is mis-load into PC computer webcam to cause it not working anymore.

my computer → click the right button of the mouse

→ “Device Manger” → Disable your pc webcam

2nd Step: Plug usb camera into the usb port of PC computer

3rd Step: Run firmware tool “USB_CAM_SF_TOOL(1)” ,  USB_CAM_SF_TOOL(1)

1)select the camera


2)load firmware “180FPS 720P Firmware 20261021.bin”

3) click the button “enable”


4) modify the SN.

5)click the button “SN” to add 1 automatically.

6) click the button “下载” to upgrade the camera with firmware



it will show PASS if success



4th Step: Plug off usb camera and re-plug in the usb camera to re-start the usb camera.

5th Step: Re-active your pc webcam, refer to 1st step.